



ASI Wall Solutions
8470 Remington Avenue, Suite C
Pennsauken, NJ 08110
T: 800.516.0105 F: 856.488.1990
asiwallsolutions.com

Casper™ Cloaking Film CARE INSTRUCTIONS

The following are washing and maintenance instructions for all your Casper™ Cloaking and Architectural Graphic Layer Films. Post these instructions where employees and/or maintenance personnel can read them since failure to follow them will irrevocably void your warranty.

DO NOT CLEAN UNTIL SIXTY (60) DAYS AFTER THE INSTALLATION DATE.

This will ensure proper care of the adhesive and edge seal used to bond the film to the glass surface.

Recommended cleaner is GDI Film Guard Cleaner & Polish and microfiber cloth.

DO NOT USE BRISTLE BRUSHES OR ANY OTHER MATERIAL THAT MIGHT SCRATCH THE SURFACE. CAUTION! DO NOT USE AMMONIA OR VINEGAR OR ANY PRODUCTS CONTAINING AMMONIA OR VINEGAR TO CLEAN THE FILM.

Some paper towels are coarse enough to scratch the Film. Repeated use of improper cleaning implements and/or solutions will damage the appearance of the Film.

GENERAL GUIDELINES

DO NOT USE ANY ADHESIVE TAPES, LABELS, OR SIGNAGE ON THE SURFACES TO WHICH THE FILM HAS BEEN APPLIED.

Under normal conditions, film will dry within 60 days.

Normal viewing conditions: View treated windows from a distance of six feet at angles of up to 45 degrees. Since a particle-free application is possible only under sterile conditions, there may be small amounts of dust or grit caught between the film and glass.

Contact asiwallsolutions.com for cleaner/polish purchasing information.